

## KIT "C-2", "C-2 NS", "C-3" & "C-3 NS" INSTRUCTIONS

CAUTION: IDENTIFY & KNOW THE CHEMICAL YOU ARE WORKING WITH AND ITS COMPATIBILITY WITH THE MATERIALS USED IN THIS KIT.

MATERIALS: STAINLESS STEEL; ZINC PLATED STEEL; SBR RUBBER; NEOPRENE CLOSED CELL FOAM.

PROPER PROTECTIVE CLOTHING MUST BE WORN AT ALL TIMES.

### SET UP



- A) DETERMINE SIZE OF PIPE & SELECT PROPER PATCH.
- B) IF POSSIBLE, APPLY PATCH TO SIDE OF LEAK AND TIGHTEN BOLTS SLIGHTLY.
- C) SELECT PROPER SIZE SOCKET.

### PATCHING PIPE

- A) SLIDE PATCH OVER LEAK AND TIGHTEN.

NOTE:  
ADDITIONAL SOFT AND HARD NEOPRENE MATERIALS INCLUDED IN THIS KIT FOR ODD SIZED PIPES, JAGGED EDGED LEAKS OR WHEREVER YOU MAY NEED IT.

